# KHADAS

Edge2 Quickstart Guide

Setup

9~20V

1

OOWOW Introduction
• Edge2 comes with the OOWOW embedded service.
• Use OOWOW to install your preferred OS directly from the Cloud.
• OOWOW will start automatically if the device storage is empty.
• Control Edge2 with a display and keyboard, or remotely over WiFi.
• With OOWOW you will always be in control of your Edge2.

Activate OOWOW: hold `Function` and press `Reset`
Activate Hotspot: press `Function` after OOWOW starts
Network Name: edge2-xxxxx (last 5 digits of serial no.)
Further information: https://docs.khadas.com/oowow

Website Introduction
• For more documentation and technical information, you can visit docs.khadas.com.
• If you encounter technical issues during development, seek help at forum.khadas.com.
• To purchase additional accessories, please visit shop.khadas.com.

Data Download Instruction
• Schematics: dl.khadas.com/products/edge2/schematic/
• Datasheets: dl.khadas.com/products/edge2/datasheet/
• Specification: dl.khadas.com/products/edge2/specs/
• 2D DXF: dl.khadas.com/products/edge2/dxf/
• 3D CAD: dl.khadas.com/products/edge2/cad/

After-Sales Service
Please email support@khadas.com if you have any after-sales related questions.

USB 3.0 (1500mA)
USB-C (3.1 & DP)
HDMI (Output)
USB-C (PD Only)
USB 2.0 (1300mA)

RGB LED2
RGB LED1

PWM Fan Header

RTC Battery

Reset

SPI Flash

Function

MHF4 Antennas (WiFi & BT)

Power

G-Sensor

KHADAS
Edge2 V11
2206 2225

Digital Microphone
Camera1
Camera2
Camera3
Digital Microphone

3
4

Pogo Pin

XPWR
Pads

IO1

IO2

DSI1

DSI2

To get started, visit
docs.khadas.com/edge2